


TOOLING SYSTEM

Unit : mm (inch)

PUMA 4100

Standard


* () Supply quantity
 () 10ST
 () 12ST



PUMA 5100

Standard

* () Supply quantity
 () 10ST
 () 12ST




TOOLING SYSTEM | TOOL INTERFERENCE

Unit : mm (inch)

PUMA 4100M / LM / XLM, PUMA 5100M / LM / XLM / LY


Standard

* () Supply quantity



Tool interference

PUMA 4100 (10 station)



PUMA 4100 (12 station)

